

## Tail Cuff (Sensor) Stand

BLOOD PRESSURE

RESTRAINTERS

The IITC sensor cuff stand is used to replace the animal restrainer when studies call for animals to be anesthetized, operated on or during MRI studies. The sensor stand is used to keep the sensor vertical on the tail. The sensor stand accommodates all five IITC sensors (tail cuffs).

One year warranty

CATHETERS

ANALGESIA

BEHAVIORAL/ACTIVITY

ANIMAL RESPIRATORS

SYRINGE PUMPS

TEMPERATURE PROBES

Part #	Description
25	Sensor (Tail Cuff) Stand

